

SCHEDULE A

SPRINKLING REGULATIONS

These restrictions apply to ALL residents within the Beaver Falls Waterworks District.

Level 1

If your house number is an odd number, you will water on Tuesday, Thursday and Saturday from 6am-10am and 6pm-10pm. For underground Systems – 12:00 midnight to 4:00 a.m.

If your house number is even, you will water on Wednesday, Friday and Sunday from 6am-10am and 6pm-10pm.

For underground systems – 12:00 midnight to 4:00 a.m.

Monday is an off day for **all** residents absolutely **NO** watering.

Level 2

Odd numbered houses Tuesday and Saturday from 6am-9am and 6pm-9pm. For underground systems – 12:00 midnight to 2:00 a.m.

Even numbered houses Wednesday and Sunday from 6am-9am and 6pm-9pm. For underground systems – 12:00 midnight to 2:00 a.m.

Lawn and gardening watering only there is to be absolutely no driveway or vehicle cleaning.

Level 3

Even numbered houses watering of **vegetable gardens only** on Wednesday and Saturday from 6am-8am and 6pm-8pm.

For underground systems – 12:00 midnight to 1:00 a.m.

Odd numbered houses watering of **vegetable gardens only** on Thursday and Sunday from 6am-8 am and 6pm-8pm. For underground systems – 12:00 midnight to 1:00 a.m.

Level 4

No watering

Regulations will be throughout the year NO open hoses at any time. All hoses in use must have a nozzle or sprinkler attached to the outlet end. ONLY one sprinkler per household on manually controlled systems can be used at any one time. Automatic Systems are not to be used in conjunction with manually controlled systems unless approved by the board.

Excessive sprinkling on driveways and sidewalks is not permitted.

A soaker hose is considered the same as an above ground sprinkler.

In the event of low aquifer levels Sprinkling Regulations Level 2, Level 3 and Level 4 will come into effect. A notice will be sent out and posted on the BFWD website.

UNDERGROUND SPRINKLERS:

All underground systems **MUST** have a back flow preventer that is accessible and serviceable. Maintenance is the responsibility of the homeowner and **MUST** have a rain sensor. Maximum total water consumption is **5GPM (Imperial Gallons)**. Once a new system is in place it should be inspected by Beaver Falls Waterworks District maintenance.

Individuals in non-compliance of the sprinkler regulations will be penalized – There shall be one written notice of regulations, which is hereby given to all water users. - First Offence – one written warning - Second Offence – water shut off DISCONNECTION FEE AND RECONNECTION FEE is seventy five dollars (\$75.00) each.

Your co-operation is greatly appreciated, for conserving our valuable water source and for being Water Smart. If you have any questions, please contact The Beaver Falls Waterworks District at 250-367-0255.